

C5 shift knob removal

1. Pry out the shift pattern cap by inserting a small, flat-blade screwdriver tip in between the cap and the knob.



2. Lock the needle nose Vise-grips or regular needle nose pliers onto the sides of the steel key that is inside the knob. Make sure that the Vise-grip pliers are locked very firmly onto the key; otherwise, the tips of the pliers will slide up during the next step.



3. Once the key is removed, unthread the shift knob by spinning it counter-clockwise. Install the supplied locking nut and if available install some tread locker. Screw on the knob (do not bottom out the knob) to desired position and then lock the jam nut up against it.